
Service Manual

High Speed Combination Oven



AXP520

MXP520

P1333603M

P1333604M

50 Hz
June 2009



16400004

TABLE OF CONTENTS

IMPORTANT INFORMATION	1
IMPORTANT SAFETY INFORMATION	2-5
Oven Specifications	6
Oven Construction	7-12
Oven Performance Test	13-14
Troubleshooting	15-18
Display Diagnostics	19
Service Test	20-27
Touch Screen Calibration	28
Component Test Procedures	29-30
Quick Start Reference Guide	31-34
EZ Card Programming	35
Wiring Diagram	36
Schematic Diagram	37

Important Information

Important Notices for Servicers and Consumers

ACP will not be responsible for personal injury or property damage from improper service procedures. Pride and workmanship go into every product to provide our customers with quality products. It is possible, however, that during its lifetime a product may require service. Products should be serviced only by a qualified service technician who is familiar with the safety procedures required in the repair and who is equipped with the proper tools, parts, testing instruments and the appropriate service information. IT IS THE TECHNICIANS RESPONSIBILITY TO REVIEW ALL APPROPRIATE SERVICE INFORMATION BEFORE BEGINNING REPAIRS.



WARNING

To avoid risk of severe personal injury or death, disconnect power before working/servicing on appliance to avoid electrical shock.

To locate an authorized servicer please contact:

ComServ Support Center



Web Site

WWW.AMANACOMMERCIAL.COM

Telephone Number

1-866-426-2621 or 319-368-8195

E-Mail: commercialservice@acpsolutions.com

Recognize Safety Symbols, Words, and Labels



DANGER

DANGER— Immediate hazards which WILL result in severe personal injury or death.



WARNING

WARNING— Hazards or unsafe practices which COULD result in severe personal injury or death.



CAUTION

CAUTION— Hazards or unsafe practices which COULD result in minor personal injury, product or property damage.

Important Safety Information



WARNING

Read the following information to avoid possible exposure to microwave radiation:

The basic design of the Microwave Oven makes it an inherently safe device to both use and service.

However, there are some precautions which should be followed when servicing the microwave to maintain this safety. These are as follows:

1. Always operate the unit from an adequately grounded outlet. Do not operate on a two-wire extension cord.
2. Before servicing the unit (if unit is operable) perform the microwave leakage test.
3. The oven should never be operated if the door does not fit properly against the seal, the hinges or hinge bearings are damaged or broken; the choke is damaged, (pieces missing, etc.); or any other visible damage can be noted. Check the choke area to ensure that this area is clean and free of all foreign matter.
4. If the oven operates with the door open and produces microwave energy, take the following steps:
 - A. Tell the user not to operate the oven.
 - B. Contact ACP ComServ immediately.
5. Always have the oven disconnected when the outer case is removed except when making the "live" tests called for in the Service Manual. Do not reach into the equipment area while the unit is energized. Make all connections for the test and check them for tightness before plugging the cord into the outlet.
6. Always ground the capacitors on the magnetron filter box with an insulated-handle screwdriver before working in the high voltage area of the equipment compartment. Some types of failures will leave a charge in these capacitors and the discharge could cause a reflex action which could make you injure yourself.
7. Always remember that in the area of the transformer there is HIGH VOLTAGE. When the unit is operating keep this area clear and free of anything which could possibly cause an arc or ground, etc.
8. Do not for any reason defeat the interlock switches there is not valid reason for this action at any time; nor will it be condoned by ACP.
9. IMPORTANT: Before returning a unit to a customer, be sure to check for proper switch interlock action.
10. The Microwave Oven should never be operated with any components removed and/or bypassed or when any of the safety interlocks are found to be defective, or when any of the seal surfaces are defective, missing, or damaged.
11. All microwave ovens meet all requirements of the radiation control for Health and Safety Act of 1968. Due to measurement uncertainties, the maximum leakage for the field will be $4\text{mw}/\text{cm}^2$.
12. To ensure that the unit does not emit excessive microwave leakage and to meet the Department of Health and Human Services guidelines, check the oven for microwave leakage using a microwave oven leakage meter that complies with US Government CDRH / FDA / DHHS requirements and or any other local government requirements. The maximum leakage level allowed by ACP is $4\text{mw}/\text{cm}^2$.
13. If servicer encounters an emission reading over $4\text{mw}/\text{cm}^2$, the servicer is to cease repair and contact the ACP ComServ Department immediately for further direction. ACP will contact the proper Government Agency upon verification of the test results.

Important Safety Information



Recognize this symbol as a SAFETY message



WARNING

When using electrical equipment, basic safety precautions should be followed to reduce the risk of burns, electrical shock, fire, or injury to persons.

1. READ all instructions before using equipment.
2. READ AND FOLLOW the specific "PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY".
3. This equipment **MUST BE GROUNDED**. Connect only to properly GROUNDED outlet. See "GROUNDING INSTRUCTIONS".
4. Install or locate this equipment **ONLY** in accordance with the installation instructions in this manual.
5. Some products such as whole eggs and sealed containers, for example, closed glass jars may explode and **SHOULD NOT** be HEATED in this oven.
6. Use this equipment **ONLY** for its intended use as described in this manual. Do not use corrosive chemicals or vapors in this equipment. This type of oven is specifically designed to heat or cook. It is not designed for industrial or laboratory use.
7. As with any equipment, **CLOSE SUPERVISION** is necessary when used by **CHILDREN**.
8. **DO NOT** operate this equipment if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped.
9. This equipment, including power cord, must be serviced **ONLY** by qualified service personnel. Special tools are required to service equipment. Contact nearest authorized service facility for examination, repair, or adjustment.
10. **DO NOT** cover or block filter or other openings on equipment.
11. **DO NOT** store this equipment outdoors. **DO NOT** use this product near water, for example, near a kitchen sink, in a wet basement, or near a swimming pool etc.
12. **DO NOT** immerse cord or plug in water.
13. Keep cord **AWAY** from **HEATED** surfaces.
14. **DO NOT** let cord hang over edge of table or counter.
15. See door cleaning instructions in "Care and Cleaning" section.
16. For commercial use only.



CAUTION

To reduce risk of fire in the oven cavity:

- a. **DO NOT** overcook food. Carefully attend equipment if paper, plastic, or other combustible materials are placed inside the oven to facilitate cooking.
- b. Remove wire twist-ties from paper or plastic bags before placing bag in oven.
- c. **KEEP** oven **DOOR CLOSED**, turn oven off, and disconnect the power cord, or shut off power at the fuse or circuit breaker panel, if materials inside the oven should ignite. Fire may spread if door is opened.
- d. **DO NOT** use the cavity for storage. **DO NOT** leave paper products, cooking utensils, or food in oven.

SAVE THESE INSTRUCTIONS

Important Safety Information



CAUTION

To avoid risk of personal injury or property damage, observe the following:

1. Briskly stir or pour liquids before heating with microwave energy to prevent spontaneous boiling or eruption. Do not overheat. If air is not mixed into a liquid, liquid can erupt in oven or after removal from oven.
2. Do not deep fat fry in oven. Fat could overheat and be hazardous to handle.
3. Do not cook or reheat eggs in shell or with an unbroken yolk using microwave energy. Pressure may build up and erupt. Pierce yolk with fork or knife before cooking.
4. Pierce skin of potatoes, tomatoes, and similar foods before cooking with microwave energy. When skin is pierced, steam escapes evenly.
5. Do not operate equipment without load or food in oven cavity.
6. Do not use regular cooking thermometers in oven. Most cooking thermometers contain mercury and may cause an electrical arc, malfunction, or damage to oven.
7. Do not heat baby bottles in oven.
8. Never use paper, plastic, or other combustible materials that are not intended for cooking.
9. When cooking with paper, plastic, or other combustible materials, follow manufacturer's recommendations on product use.
10. Do not heat sealed containers or plastic bags in oven. Food or liquid could expand quickly and cause container or bag to break. Pierce or open container or bag before heating.
11. To avoid pacemaker malfunction, consult physician or pacemaker manufacturer about effects of microwave energy on pacemaker.

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- a. DO NOT attempt to operate this oven with the door open since open-door operation can result in harmful exposure to microwave energy. It is important not to defeat or tamper with the safety interlocks.
- b. DO NOT place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- c. DO NOT operate the oven if it is damaged. It is particularly important that the oven door close properly and that there is no damage to the: (1) door (bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.
- d. The oven should NOT be adjusted or repaired by anyone except properly qualified service personnel.

SAVE THESE INSTRUCTIONS

Important Safety Information



WARNING

Precautions to be observed before and during servicing to avoid possible exposure to excessive microwave energy, or electrical shock disconnect power to oven.

- Do not operate or allow oven to be operated with door open.
- Make the following safety checks on all ovens to be serviced before activating the magnetron or other microwave source, and make repairs as necessary:
 - Interlock operation
 - Proper door closing
 - Seal and sealing surfaces (arcing, wear, and other damage)
 - Damage to or loosening of hinges and latches
 - Evidence of dropping or abuse
- Before turning on microwave power for any service test or inspection within the microwave generating compartments, check the magnetron, waveguide or transmission line, and cavity for proper alignment, integrity, and connections.
- Any failed or misadjusted components in the interlock, monitor, door seal, and microwave generation and transmission systems shall be repaired, replaced or adjusted by procedures described in this manual before oven is released to the consumer.
- Check microwave leakage to verify compliance with the federal performance standard should be performed on each oven prior to release to the consumer.



WARNING

To avoid risk of electrical shock, injury or death; make sure these grounding instructions are followed.

Grounding Instructions



WARNING

Do not remove grounding prong when installing grounded appliance in a home or business that does not have three wire grounding receptacle, under no condition is grounding prong to be cut off or removed. It is the personal responsibility of the consumer to contact a qualified electrician and have properly grounded three prong wall receptacle installed in accordance with appropriate electrical codes.



WARNING

To avoid the risk of electrical shock or death, do not alter the plug.



WARNING

To avoid the risk of electrical shock or death, this equipment must be grounded.

This equipment **MUST** be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This oven is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.


Consult a qualified electrician or servicer if grounding instructions are not completely understood, or if doubt exists as to whether the equipment is properly grounded.

Do not use an extension cord. If the product power cord is too short, have a qualified electrician install an appropriate receptacle. This oven should be plugged into a separate 50 or 60 hertz circuit with the electrical rating as shown in the appropriate drawing. Models operate with a 208 or 230 supply voltage. When an oven is on a circuit with other equipment, an increase in cooking times may be required and fuses can be blown.

SPECIFICATIONS


Models	AXP520 MXP520	P1333603M P1333604M
Power Source		
Voltage AC	230/240 VAC	
Amperage (Single Unit)	30 A	
Frequency	50Hz	
Single Phase, 3 wire grounded	X	
Receptacle	IEC 309	
Plug	IEC 309	
Power Output – Microwave		
Nominal microwave energy (IEC705)	2200 Watts	
Minimum Temperature Rise (ΔT)	22°F / 12°C	
Operating Frequency	2450 MHz	
Power Consumption	5700 Watts	
Microwave only	4200 Watts	
Convection fan	425 Watts / 6200 RPM	
Radiant heater	3000 Watts	
Convection heater	2000 Watts	
Combination	5300Watts	
Dimensions		
Cabinet (in / cm)		
Width	25"	63.5 cm
Height	20 .25"	51 cm
Depth (includes bracket on back)	25.625"	65 cm
Oven Interior (in / cm) – useable space		
Width	16.0"	41 cm
Height	7.75"	20 cm
Depth	15.0"	38 cm
Weight (lbs. / kg)		
Uncrated	150 lbs.	68 kg
Crated	175 lbs.	79 kg

OVEN CONSTRUCTION- PANELS (TOP & SIDE)



OVEN CONSTRUCTION-

OVEN CONSTRUCTION CONTROL PANEL ASSEMBLY



Caution: Do not handle touch screen display by the sides. This may damage the display circuitry. Handle using the corners.

OVEN CONSTRUCTION-

Circuit Boards

Power Relay

Limiter


Triac

Thermocouple

Temp Sensor (RTD)

Cooling Fans


Convection Motor



***Note: If Main Fuse (F1) is blown
replace Relay Monitor Board, Power Relay &
Interlock Switch Assembly.**

OVEN CONSTRUCTION-

HV Transformers
Magnetrons
Fuses
Sensor
Triac's
Magnetron TCO's
Capacitor / Diodes




***Note: If Main Fuse (F1) is blown
replace Relay Monitor
Board, Power Relay & Interlock
Switch Assembly.**

OVEN CONSTRUCTION-

Oven Switch Replacement & Interlock Switch Adjustment

Attach Ohm-Meter to
Wire Harness Connectors



Switch Adjustment
Lever

Figure 1

Mounting Screw

Adjustment

Switch Test:

When the door is opened or closed, the left door hinge activates the secondary / monitor switches.

1. Connect an ohm-meter to wire harness (as shown in figure 1, to verify switch activation).

Note: The switch assembly should activate when the door gap is approximately 1/4 inch (6mm).

Switch Adjustment:

1. Loosen mounting screws.
2. Slide adjustment lever for proper switch activation.
3. Tighten mounting screws.
4. Preheat oven to set temperature and verify switch adjustment settings and function.


Note: To ensure proper switch adjustment, the switch mounting **MUST** be tightened after each adjustment prior to testing the door alignment.

Replacement

Removal:

1. Remove switch assembly mounting screw.
2. Push switch assembly 1/2 inch (13mm) towards back of oven.
3. Twist mounting leg towards oven cavity to release mounting tab.
4. Push assembly towards back of oven to remove.

Note: New replacement switch assembly has been adjusted at the factory, no adjustment should be necessary.



OVEN CONSTRUCTION-


Antenna Motor

Cam

Gear Assembly


Antenna

Rivet, Plastic



See Detail Below

***Note:** Plastic Rivet
cannot be reused.



OVEN PERFORMANCE TEST

Note: To run Oven Performance Test the, OVEN CAVITY MUST BE AT ROOM TEMPERATURE, and the display must read MICROWAVE ONLY mode. See below using oven as a microwave oven. If MICROWAVE ONLY is not in display you must go to User Options and activate MICROWAVE ONLY option.

Changing User Options:

1. Oven must be OFF.
2. Press and hold Pad "2" for 5 seconds.



3. Rotate dial to highlight: ALLOW MICROWAVE ONLY mode.
4. Press SAVE.

USING OVEN AS A MICROWAVE OVEN

This option is only available if the oven cavity temperature is less than 200°F.

When user option MICROWAVE ONLY is set as a default, the MICROWAVE ONLY button appears on the PREHEAT MENU.

See page 14 for Oven Performance Test procedure.


To run Performance Test using microwave only follow these steps:

1. Place filled test bowl in oven.
2. Press MICROWAVE ONLY button.



3. Press manual cook.
4. Press Pad 3 twice for 33 seconds.
5. Press Start.
6. Oven will beep, remove test bowl from oven.
7. Press OFF to return to PREHEAT MENU.

PREHEAT MENU



OVEN PERFORMANCE TEST

All Amana and Menumaster microwave oven power outputs are rated using the IEC705 standards. Using the IEC705 test method requires precision measurements and equipment that is not practical to be performed in the field. Using the test shown below will indicate if the oven performance is satisfactory.

Test equipment required:

- 1000 ml test container and thermometer.
- Digital watch / watch with a second hand for use on ovens with electromechanical timers.

Important Notes:

- Low line voltage will cause low temperature rise / power output.
- Ovens must be on a dedicated circuit, properly grounded, and polarized. Other equipment on the same circuit may cause a low temperature rise / power output.
- This test and results are not a true IEC705 test procedures and are only intended to provide servicers with an easy means of determining if the microwave oven cooking output is correct.

Procedure

1. Fill the test container to the 1000 ml line with cool tap water.

NOTE: Water temperature should be approximately 60°F / 16°C

2. Using the thermometer, stir water for five to ten seconds; measure, and record the temperature (T1).
3. Place test container of water in the center of oven cavity and close door.
4. Heat the water for a 33-second full power cycle.

NOTE: Use a digital watch or a watch with a second hand for ovens with electromechanical timers.


5. At end of the cycle, remove test container. Using the thermometer, stir water for five to ten seconds and record temperature (T2).
6. Subtract the starting water temperature (T1), from the ending water temperature (T2) to obtain the temperature rise (ΔT).
7. If the temperature rise (ΔT) meets or exceeds the minimum, the test is complete. If the temperature rise (ΔT) fails to meet the minimum temperature rise, test the line voltage to verify it is correct. Then repeat steps 1-6 making sure to change the water. If the temperature rise (ΔT) fails to meet the minimum temperature rise again the oven will require service.

Minimum Temperature Rise at Thirty -Three (33) Seconds Run Time

ΔT (°F)	Cooking Power Output	ΔT (°F)	Cooking Power Output	ΔT (°C)	Cooking Power Output	ΔT (°C)	Cooking Power Output
10.....	1000	20	2000	5	1000	11	2000
11.....	1100	21	2100	5.5.....	1100	11.5	2100
12.....	1200	22	2200	6.5.....	1200	12	2200
14.....	1400	24	2400	7.5.....	1400	13	2400
17.....	1700	25	2500	9.5.....	1700	13.5	2500
18.....	1800	27	2700	10	1800	15	2700
19.....	1900	30	3000	10.5	1900	16.5	3000


Troubleshooting

POWER UP CONDITION




Troubleshooting

PREHEAT CONDITION



Troubleshooting


MICROWAVE CONDITION



Troubleshooting

OPERATIONAL CODES

During oven operation the display may indicate one of the following:




Display Diagnostics


ERROR CODES:

<u>DISPLAY</u>	<u>DESCRIPTION</u>	<u>CORRECTIVE ACTION</u>
B0	Touch Panel	Replace Touch Panel
B1	Touch Panel	Replace Touch Panel
C-0	Temp Sensor (RTD) (open)	Replace Temp Sensor
C-1	Temp Sensor (RTD) (shorted)	Replace Temp Sensor
C-2	Temp Sensor (RTD) (out of range)	Replace Temp Sensor
D-0	Thermocouple (RTD) (open)	Replace Thermocouple
D-1	Thermocouple (RTD) (shorted)	Replace Thermocouple
D-2	Thermocouple (RTD) (out of range)	Replace Thermocouple
G-0	Oven Exceeded Max. Temp.	Unplug / Plug oven in
G-2	Magnetron TCO	Perform service test
G-2	Cooling Motor	Perform service test
H-0	Signal Missing	Plug disconnected from J1 on main board
H-1	Main Board Set Point Incorrect.	Unplug / Plug oven in
H-2	Main Board	Replace main board
H-3	Main Board	Replace main board

NOTE: While in the service test the error history can be cleared by pressing and holding Pad One. (Page 27)

Service Test

Access to Service Mode	
<p>Screen</p>  <p>Hidden Pad</p>	<p>While at the Main Screen, press the following sequence on the keypad:</p> <p>NOTE: The “MICROWAVE ONLY” button may or may not be present.</p> <ol style="list-style-type: none"> 1. Press OFF pad until PRESS TO PREHEAT appears. 2. Press Hidden Pad. 3. Press pads 1 - 3 - 5 - 7 - 9 <p>The display indicates SERVICE MODE.</p>


Oven Information	1
<p>Screen</p> 	<p>This screen is Oven Information showing the versions of software in the control boards and information about door cycles and tube hours.</p> <p>NEXT TEST: Press this pad to go to the next Service Mode Test</p> <p>PREV TEST: Press this pad to go to the previous Service Mode Test</p> <p>CLEAR INFO: Press this pad to reset the Door Cycles and Tube Hours back to zero.</p> <p>EXIT: Press this pad to return to the ovens Main Menu</p>


Service Test

Manual Operation of Magnetrons #1 & #2		2
Screen	<div> <p>SERVICE MODE</p> <p>MAGNETRONS #1 & #2</p> <p>MAGNETRON #1: 9 AMPS</p> <p>MAGNETRON #2: 9 AMPS</p> <p>ACCEPTABLE RANGE:</p> <div> <div>NEXT TEST</div> <div>PREV TEST</div> <div>CANCEL</div> <div>TURN ON</div> </div> </div>	<p>This screen will allow operation of Magnetron #1 and #2 together and show the number of amps being drawn.</p> <p>NEXT TEST: Press this pad to go to the next Service Mode Test</p> <p>PREV TEST: Press this pad to go to the previous Service Mode Test</p> <p>TURN ON: This pad will toggle between turning the magnetrons on and off.</p> <p>CANCEL: Press this pad to return to the Main Menu</p> <p>RANGE: Under normal operation, each mag's amp draw should be 5 – 12 amps.</p>

Manual Operation of Magnetron #1		3
Screen	<div> <p>SERVICE MODE</p> <p>MAGNETRON #1</p> <p>CURRENT DRAW: 9 AMPS</p> <p>ACCEPTABLE RANGE:</p> <div> <div>NEXT TEST</div> <div>PREV TEST</div> <div>CANCEL</div> <div>TURN ON</div> </div> </div>	<p>This screen will allow operation of Magnetron #1 and show the number of amps being drawn.</p> <p>NEXT TEST: Press this pad to go to the next Service Mode Test</p> <p>PREV TEST: Press this pad to go to the previous Service Mode Test</p> <p>TURN ON: This pad will toggle between turning the magnetron on and off.</p> <p>CANCEL: Press this pad to return to the Main Menu</p> <p>RANGE: Under normal operation, the amp draw should be 5 – 12 amps.</p>

Service Test


Manual Operation of Magnetron #2		4
Screen		<p>This screen will allow operation of Magnetron #2 and show the number of amps being drawn.</p> <p>NEXT TEST: Press this pad to go to the next Service Mode Test</p> <p>PREV TEST: Press this pad to go to the previous Service Mode Test</p> <p>TURN ON: This pad will toggle between turning the magnetron on and off.</p> <p>CANCEL: Press this pad to return to the Main Menu</p> <p>RANGE: Under normal operation, the amp draw should be 5 – 12 amps.</p>


Convection Heater		5
Screen		<p>This screen will allow operation of the convection heater and show the number of amps being drawn.</p> <p>NEXT TEST: Press this pad to go to the next Service Mode Test</p> <p>PREV TEST: Press this pad to go to the previous Service Mode Test</p> <p>TURN ON: This pad will toggle between turning the heater on and off.</p> <p>CANCEL: Press this pad to return to the Main Menu</p> <p>RANGE: Under normal operation, the amp draw should be 5 – 12 amps.</p>

Service Test



Radiant Heater	6
<p>Screen</p> <div data-bbox="207 321 722 982"> <p>SERVICE MODE</p> <p>RADIANT HEATERS</p> <p>CURRENT DRAW: 12 AMPS</p> <p>ACCEPTABLE RANGE:</p> <div> <div>NEXT TEST</div> <div>PREV TEST</div> <div>CANCEL</div> <div>TURN ON</div> </div> </div>	<p>This screen will allow operation of the radiant heater and show the number of amps being drawn.</p> <p>NEXT TEST: Press this pad to go to the next Service Mode Test</p> <p>PREV TEST: Press this pad to go to the previous Service Mode Test</p> <p>TURN ON: This pad will toggle between turning the heater on and off.</p> <p>CANCEL: Press this pad to return to the Main Menu</p> <p>RANGE: Under normal operation, the amp draw should be 10 – 16 amps.</p>
Convection Fan – Low Speed	7
<p>Screen</p> <div data-bbox="207 1140 722 1822"> <p>SERVICE MODE</p> <p>CONVECTION FAN</p> <p>LOW</p> <p>CURRENT DRAW: 0.5 AMPS</p> <p>ACCEPTABLE RANGE:</p> <div> <div>NEXT TEST</div> <div>PREV TEST</div> <div>CANCEL</div> <div>TURN ON</div> </div> </div>	<p>This screen will allow operation of the convection fan at a low speed and show the number of amps being drawn.</p> <p>NEXT TEST: Press this pad to go to the next Service Mode Test</p> <p>PREV TEST: Press this pad to go to the previous Service Mode Test</p> <p>TURN ON: This pad will toggle between turning the convection fan on and off at a low speed.</p> <p>CANCEL: Press this pad to return to the Main Menu</p> <p>RANGE: Under normal operation, the amp draw is too low to read.</p>

Service Test


Convection Fan – High Speed	8
<p>Screen</p> 	<p>This screen will allow operation of the convection fan at a high speed and show the number of amps being drawn.</p> <p>NEXT TEST: Press this pad to go to the next Service Mode Test</p> <p>PREV TEST: Press this pad to go to the previous Service Mode Test</p> <p>TURN ON: This pad will toggle between turning the convection fan on and off at a high speed.</p> <p>CANCEL: Press this pad to return to the Main Menu</p> <p>RANGE: Under normal operation, the amp draw should be 0.6 – 2.6 amps. (It may not read amps)</p>


Cooling Fan	9
<p>Screen</p> 	<p>This screen will allow operation of the cooling fan show the number of amps being drawn.</p> <p>NEXT TEST: Press this pad to go to the next Service Mode Test</p> <p>PREV TEST: Press this pad to go to the previous Service Mode Test</p> <p>TURN ON: This pad will toggle between turning the cooling fan on and off.</p> <p>CANCEL: Press this pad to return to the Main Menu</p> <p>RANGE: Under normal operation, the amp draw should be 0.9 – 2.5 amps. (It may not read amps)</p>

Service Test


Antenna Motor	10
<p>Screen</p> 	<p>This screen will allow operation of the antenna motor show the number of amps being drawn.</p> <p>NEXT TEST: Press this pad to go to the next Service Mode Test</p> <p>PREV TEST: Press this pad to go to the previous Service Mode Test</p> <p>TURN ON: This pad will toggle between turning the antenna motor on and off.</p> <p>CANCEL: Press this pad to return to the Main Menu</p> <p>RANGE: Under normal operation, the amp draw may be to low to read.</p>
RTD Status	11
<p>Screen</p> 	<p>This screen will show the temperatures being reported to the RTD's in the oven. The maximum temps seen by the controller are also recorded for diagnostic purposes.</p> <p>NEXT TEST: Press this pad to go to the next Service Mode Test</p> <p>PREV TEST: Press this pad to go to the previous Service Mode Test</p> <p>CANCEL: Press this pad to return to the Main Menu</p> <p>CLEAR INFO: Press this pad to reset the Maximum RTD temps to zero.</p>


Service Test

Memory / Network Status	12
<p>Screen</p> 	<p>This screen will show which memory chips are present and if the oven is hooked up to an external network.</p> <p>NEXT TEST: Press this pad to go to the next Service Mode Test</p> <p>PREV TEST: Press this pad to go to the previous Service Mode Test</p> <p>CANCEL: Press this pad to return to the Main Menu</p>

Error List	13
<p>Screen</p> 	<p>This screen will show a description of the types of errors that can occur.</p> <p>NEXT TEST: Press this pad to go to the next Service Mode Test</p> <p>PREV TEST: Press this pad to go to the previous Service Mode Test</p> <p>CANCEL: Press this pad to return to the Main Menu</p>

Service Test

Error History	14
<p>Screen</p> 	<p>This screen will show the previous error codes that have occurred in the oven.</p> <p>NEXT TEST: Press this pad to go to the next Service Mode Test</p> <p>PREV TEST: Press this pad to go to the previous Service Mode Test</p> <p>SCROLL: This pad will advance through the history of the error codes. (1-10)</p> <p>CANCEL: Press this pad to return to the Main Menu</p> <p>Note: To clear codes: Press and hold Pad 1 until Code(s) disappear.</p>


Voltage Switching	15
<p>Screen</p> 	<p>This screen will show the line voltage detected by the oven.</p> <p>NEXT TEST: Press this pad to go to the next Service Mode Test</p> <p>PREV TEST: Press this pad to go to the previous Service Mode Test</p> <p>CANCEL: Press this pad to return to the Main Menu</p>

Calibration

Touch Screen Calibration

To calibrate the touch screen perform the following steps.

1. The oven must be plugged In.
2. Stand-by screen must be in the Display.
3. Press the **Hidden Pad**.











4. Press Pads 4, 5, 6.
5. Press Directly ON small Square in the Display.
The Square will move to a different location on the Display.
6. Press Directly On the small Square in the Display again until the square disappears.
7. Press the 0 Pad.
8. A small box will appear in the top left square. Press on each box and the small square will follow. After you have touched all the boxes and the small square followed you go to step 9.
9. Press the 0 pad to return to the Stand-by screen.

Component Testing Procedures



WARNING

To avoid risk of electrical shock, personal injury or death; disconnect power to oven and discharge capacitor before servicing, unless testing requires power.















Illustration	Component	Test	Results
	Thermal cutout	Disconnect all wires from TCO. Measure resistance across terminals. Magnetron TCO	Open at 300°F (149°C) and closed at 257°F (125°C)
	Diode	Discharge Capacitor Remove diode lead from capacitor and connect ohmmeter. Reverse leads for second test.	Infinite resistance should be measured in one direction and 50KΩ or more in the opposite direction. NOTE: Ohmmeter must contain a battery of 6 volts minimum.
 Triac (TR1) (TR2) (TR3) (TR4)	Triac	Disconnect wires to triac. Measure resistance from: MT1 to MT2 MT1 to Gate MT2 to Gate All terminals to ground Measure voltage from: MT1 to Gate	Caution - Do not operate oven with wire to terminal MT2 removed. Infinite Approximately 15 Ω, then reverse meter leads 30 Ω Infinite Infinite 0.8 VAC when energized. If no voltage, check H.V. board and wiring.
	Capacitor	Discharge Capacitor Remove wires from capacitor terminals and connect ohmmeter, set on highest resistance scale to terminals. Also check between each terminal and capacitor case.....	Between Terminals: Meter should momentarily deflect towards zero then return to over 5 MΩ. If no deflection occurs, or if continuous deflection occurs, replace capacitor. Terminal to Case: Infinite resistance
	Snubber assembly	Disconnect wires to snubber. Measure resistance across terminals.....	Infinite
	Magnetron	Discharge Capacitor Remove wires from magnetron and connect ohmmeter to terminals. Also check between each terminal and ground.	Between Terminals: Less than 1 Ω Each terminal to ground measures Infinite resistance. Note: This test is not conclusive. If oven does not heat and all other components test good replace the magnetron and retest.
	Cooling blower motor	Measure voltage at motor Measure resistance across leads.....	Approximately 24 vdc at incoming leads Approximately 24K Ω at incoming leads
	Stirrer motor	Remove all wires from terminals. Measure resistance from: Terminal to terminal.....	Approximately 29K Ω

Component Testing Procedures



WARNING

To avoid risk of electrical shock, personal injury or death; disconnect power to oven and discharge capacitor before servicing, unless testing requires power.

Illustration	Component	Test	Results
	Transformer	Discharge Capacitor Remove all wires from terminals. Measure resistance from: 230 to COM..... 208 to COM..... 230 to Ground..... 208 to Ground..... Terminal 5 to 6..... Terminal 4 to Ground.....	Less than 1 Ω Less than 1 Ω Infinite Infinite Less than 1 Ω Approximately 46 Ω
	Convection blower motor	Use Service test to verify operation ST1-1 to ST1-3 BK BU ST2 GN - YL - OR -BU	Line Voltage Disconnect ST2 Fan should operate at High Speed
	Convection heating element	Disconnect wires from terminals. Measure resistance across heating element. Element 2000 W	Approximately 19 - 22 Ω
	Cavity heating element	Disconnect wires from terminals. Measure resistance across heating element. Element 3000 W	Approximately 14 Ω
	Resistance thermal device (RTD)	Temperature 32°F (0°C) 350° (177°C)	Resistance 1000 Ω 1654 Ω
	Limiter	Red - Orange Lead Terminals Yellow - Yellow Leads disconnected from Limiter Terminal 6 - Terminal 7	Line Voltage 24vdc across yellow leads (Polarity must be correct) 0 Ω Indicates continuity
	Relay (Power) This relay contains a diode in the coil circuit.	Measure resistance from: Terminal 0 to terminal 1 (coil) 	Approximately 6 to 7 M Ω NOTE: Analog meter is recommended for measurement. NOTE: If using a digital meter it must contain a battery of 6 volts minimum.
Wire harness	High voltage board to display module harness	Test continuity of wires	Indicates continuity
	Primary switch	Com NO NC 	NC to Com Indicates continuity NO to Com Indicates infinity
	Secondary switch		NC to Com Indicates continuity NO to Com Indicates infinity
	Monitor Interlock switch		1 to 2 Indicates continuity 1 to 3 Indicates infinity

Quick Start Reference Guide | High Speed Commercial Combination Oven

Refer to Product Safety Manual for Safety Statements. Complete Owner's Manual available online

Oven Controls

The oven touch screen displays menu options. The dial, keypad and touch screen can be used to navigate through onscreen menus. **This guide will focus primarily on the dial control for menu navigation.**

Dial Menu Navigation

1. Rotate the dial clockwise to scroll through menu options.
2. The current menu selection will be highlighted.
3. To select menu item, press dial.

The icons below will be used throughout this guide to indicate when menu navigation other than the dial is necessary.



Selecting a Function




Highlight menu items by rotating the dial. Push the dial to select.

Getting Started

Preheating the Oven

This oven can be set to a preheat temperature between 200°F and 520°F (95°C and 270°C).


1. Oven must be plugged in.
2. The Preheat Temperature the oven is set to will appear at the top of the display.
2. Rotate the dial to highlight the PRESS TO PREHEAT button and press to select.
3. Oven Preheating status menu will display until oven reaches preheat temperature. The main menu screen will then appear.



Programming or Changing Preheat Setting

To program the preheat setting:


1. Oven must be plugged in.
2. Rotate dial until CHANGE TEMP is highlighted and press dial to select.
3. Rotate dial until desired temperature is displayed and press knob to select.



Cooking with Pre-programmed Pads

To cook food using pre-programmed menu items

1. After oven has preheated to the desired temperature, highlight desired menu category by rotating the dial and press to select.
2. Highlight menu item group and press dial to select.
3. Highlight item.
4. Open oven door, place food in oven and close door.
5. Push dial to start cooking process.
6. At end of cooking cycle, oven beeps and displays "DONE. REMOVE FOOD FROM OVEN"



Using MANUAL COOK


To cook food using a specific entered time and power level.

1. After oven has preheated, Select MANUAL COOK option on the menu screen by rotating dial and press to select.
2. For Stage 1, input desired cooking time using the dial. Press dial.
3. Input desired temperature. Press dial.
4. Rotate dial until desired microwave cooking power is displayed and press.
5. Rotate dial until desired cooking fan speed is displayed. Press to select.
6. Rotate dial until desired heating setting is displayed and press.
7. Repeat steps 2-6 for each cooking stage, if more than one stage is necessary.
8. Place food in oven as indicated on the oven display.
9. Press start pad or touch screen to start.



10. At end of cooking cycle, oven beeps and displays "DONE. REMOVE FOOD FROM OVEN".

Note: To interrupt cooking cycle, open door. To resume cooking, close door and press start.



Quick Start Reference Guide | High Speed Commercial Combination Oven

ACCESSING THE PROGRAM MENU


1. To access the PROGRAM MENU, select the BACK button on the main menu screen.



2. Then select PROGRAM from the READY screen.



1



2




PROGRAM MENU OVERVIEW

NEW – Add a new menu item

BACK – Go to previous screen

EDIT – Change an existing menu item

DELETE – Delete an existing menu item



ADDING OR CHANGING MAIN MENU LEVEL OR ITEM GROUP MENU

1. From PROGRAM MENU rotate dial to select NEW to add an item or EDIT to edit an existing menu item.

2. From the MENU or MENU ITEM GROUP screen select EDIT MENU (border will flash).

3. Using the dial, highlight pad you wish to program or edit and press dial to select.




4. Enter name for menu using keypad digits for letters, numbers and symbols. **[For example: Press Keypad “2” three times for letter “c”]**

When the correct letter is displayed, wait until cursor moves to the next space. If a correction is necessary, press CLEAR to erase one character at a time.






Keypad Press	Character Display
1	“ , , #, 1
2	a, b, c, A, B, C, 2
3	d, e, f, D, E, F, 3
4	g, h, i, G, H, I, 4
5	j, k, l, J, K, L, 5
6	m, n, o, M, N, O, 6
7	p, q, r, s, P, Q, R, S, 7
8	t, u, v, T, U, V, 8
9	w, x, y, z, W, X, Y, Z, 9
0	&, %, \$, 0

EDITING MAIN MENU CATEGORY SCREEN



EDITING FOOD CATEGORY SCREEN



4. Highlight SAVE button and press dial to select when item is complete. If you do not wish to save the entry, press the back button to return the oven to Program Edit without saving.
5. Press BACK button to return to READY display.


Quick Start Reference Guide | High Speed Commercial Combination Oven

ADDING ITEM TO ITEM MENU

1. Select NEW from the PROGRAM MENU to add a new item or EDIT to edit item.
2. Select category you wish to change from MAIN MENU and ITEM GROUP MENUS.
3. At the ITEM MENU, rotate dial until item to be added or changed is highlighted and press dial. The confirm screen will appear and ask you to confirm the change you're making. Touch CREATE or press knob to CONFIRM OVERWRITE. Note - When editing an item the CONFIRM OVERWRITE screen does not appear.



CREATING NEW ITEM GROUP



The cooking program menu will appear


4. For Stage 1 rotate the dial to input desired time.




5. Input desired temperature.



6. Input desired microwave power



7. Input desired fan speed



8. Input desired (IR) heating setting.



9. Press SAVE button on screen.




If necessary, repeat steps 4 through 8 for stages 2, 3, and 4.

10. Enter Item Names using letters on keypad and touch SAVE.



Keypad Press	Character Display
1	“, ’, -, #, 1
2	a, b, c, A, B, C, 2
3	d, e, f, D, E, F, 3
4	g, h, i, G, H, I, 4
5	j, k, l, J, K, L, 5
6	m, n, o, M, N, O, 6
7	p, q, r, s, P, Q, R, S, 7
8	t, u, v, T, U, V, 8
9	w, x, y, z, W, X, Y, Z, 9
0	&, %, \$, 0

COOKING PROGRAM MENU



Quick Start Reference Guide | High Speed Commercial Combination Oven

Refer to Product Safety Manual for Safety Statements. Complete Owner's Manual available online

Changing User Options



There are several option you can change to customize the operation of the oven for your business. The table below shows these options; the factory setting is shown in bold type.

1. Oven must be off. To turn oven off, press OFF button on Keypad.
2. Press and hold "2" keypad for three seconds.
3. Choose option by turning dial to highlight desired option. Press knob and the next option will be highlighted.
4. Press SAVE when finished.

Off

Option #	Setting Name	Options
1	Digit Entry	Single digit entry Double digit entry
2	Menu Setting	1 Level 2 Levels 3 Levels
3	Manual Lock	Manual cooking allowed Manual cooking not allowed
4	Program Lock	Changes to programs allowed Password needed
5	Door Open	Opening door resets timer Opening door pauses cook cycle
6	Keybeep	Off On
7	Keybeep Volume	Low Medium High
8	End of Cycle Beep	Continuous until door is opened Three beeps once Three beeps repeating
9	Keyboard Window	Off 30 Seconds 60 Seconds 120 Seconds
10	Preheat Warnings	Off Warn if oven not at temp
11	Temperature Scale	Degrees F Degrees C
12	Clean Filter	Off Displays every 7 days Displays every 30 days Displays every 90 days
13	Auto Menu	From Preheat, go to Ready From Preheat, go to Menu
14	Magnetron Control	No individual tube programming Individual Tube Programming
15	Microwave Only Mode	No microwave only mode Allow microwave only mode
16	Manual Program Save	Do not save after manual cook Save after manual cook
17	Automatic Shut Off	2 Hours 4 Hours 8 Hours Disable
18	Data Transfer	Begin Transfer: Card to Oven Begin Transfer: Oven to Card

CLEAN FILTER



When this message displays, clean the air filter thoroughly. **Cleaning the air filter will not shut off the message.** The message will automatically stop displaying after 24 hours.

Depending on microwave use and environmental conditions, the filter may need to be cleaned more or less frequently. Once the frequency is determined, set the option for the appropriate time frame.

Air filter and vents must be cleaned regularly to prevent overheating of the oven. Refer to Owner's Manual for complete cleaning instructions.

AXP520 / MXP520 EZCard Programming

To program the oven using the EZCard:

Oven must be in Standby mode (Preheat must be OFF)

1. Open protective cover from bottom of keypad.

2. Insert the EZCard into the slot located below the vertical keypad.

Note: The EZCard can be inserted forwards or backwards.

3. From Standby, press and hold the “2” pad to go to “User Options”.

4. Go to Option #18 by pressing “Prev Option” on the screen or repeatedly pressing “Next Option”

5. Select the desired operation by highlighting “Transfer card to oven” or “Transfer oven to card” with the knob.




6. Press the “Start” pad to begin the transfer (The screen will indicate transferring and indicate done when transfer is complete.)

7. Press the SAVE pad to complete the process.


Note: You can exit from programing the oven by pressing “off” keypad.

8. Remove EZCard and close the protective cover.

Standby Mode



Wiring Diagram - AXP520 P1333603M, MXP520 P1333604M



The diagram illustrates the electrical control system for a microwave oven. Key components and their connections include:

- Power Input:** L1, L2, GND, F1 (Line Filter).
- Power Supply:** J1-1, J1-3, J2-6,7, J2-8, J2-1, +24VDC, GND.
- Control Board:** J1-1, J1-2, J1-3, J1-4, J1-5, J1-6, J1-7, J1-8, J1-9, J1-10, J1-11, J1-12, J1-13, J1-14, J1-15, J1-16, J1-17, J1-18, J1-19, J1-20, J1-21, J1-22, J1-23, J1-24, J1-25, J1-26, J1-27, J1-28, J1-29, J1-30, J1-31, J1-32, J1-33, J1-34, J1-35, J1-36, J1-37, J1-38, J1-39, J1-40, J1-41, J1-42, J1-43, J1-44, J1-45, J1-46, J1-47, J1-48, J1-49, J1-50, J1-51, J1-52, J1-53, J1-54, J1-55, J1-56, J1-57, J1-58, J1-59, J1-60, J1-61, J1-62, J1-63, J1-64, J1-65, J1-66, J1-67, J1-68, J1-69, J1-70, J1-71, J1-72, J1-73, J1-74, J1-75, J1-76, J1-77, J1-78, J1-79, J1-80, J1-81, J1-82, J1-83, J1-84, J1-85, J1-86, J1-87, J1-88, J1-89, J1-90, J1-91, J1-92, J1-93, J1-94, J1-95, J1-96, J1-97, J1-98, J1-99, J1-100, J1-101, J1-102, J1-103, J1-104, J1-105, J1-106, J1-107, J1-108, J1-109, J1-110, J1-111, J1-112, J1-113, J1-114, J1-115, J1-116, J1-117, J1-118, J1-119, J1-120, J1-121, J1-122, J1-123, J1-124, J1-125, J1-126, J1-127, J1-128, J1-129, J1-130, J1-131, J1-132, J1-133, J1-134, J1-135, J1-136, J1-137, J1-138, J1-139, J1-140, J1-141, J1-142, J1-143, J1-144, J1-145, J1-146, J1-147, J1-148, J1-149, J1-150, J1-151, J1-152, J1-153, J1-154, J1-155, J1-156, J1-157, J1-158, J1-159, J1-160, J1-161, J1-162, J1-163, J1-164, J1-165, J1-166, J1-167, J1-168, J1-169, J1-170, J1-171, J1-172, J1-173, J1-174, J1-175, J1-176, J1-177, J1-178, J1-179, J1-180, J1-181, J1-182, J1-183, J1-184, J1-185, J1-186, J1-187, J1-188, J1-189, J1-190, J1-191, J1-192, J1-193, J1-194, J1-195, J1-196, J1-197, J1-198, J1-199, J1-200, J1-201, J1-202, J1-203, J1-204, J1-205, J1-206, J1-207, J1-208, J1-209, J1-210, J1-211, J1-212, J1-213, J1-214, J1-215, J1-216, J1-217, J1-218, J1-219, J1-220, J1-221, J1-222, J1-223, J1-224, J1-225, J1-226, J1-227, J1-228, J1-229, J1-230, J1-231, J1-232, J1-233, J1-234, J1-235, J1-236, J1-237, J1-238, J1-239, J1-240, J1-241, J1-242, J1-243, J1-244, J1-245, J1-246, J1-247, J1-248, J1-249, J1-250, J1-251, J1-252, J1-253, J1-254, J1-255, J1-256, J1-257, J1-258, J1-259, J1-260, J1-261, J1-262, J1-263, J1-264, J1-265, J1-266, J1-267, J1-268, J1-269, J1-270, J1-271, J1-272, J1-273, J1-274, J1-275, J1-276, J1-277, J1-278, J1-279, J1-280, J1-281, J1-282, J1-283, J1-284, J1-285, J1-286, J1-287, J1-288, J1-289, J1-290, J1-291, J1-292, J1-293, J1-294, J1-295, J1-296, J1-297, J1-298, J1-299, J1-300, J1-301, J1-302, J1-303, J1-304, J1-305, J1-306, J1-307, J1-308, J1-309, J1-310, J1-311, J1-312, J1-313, J1-314, J1-315, J1-316, J1-317, J1-318, J1-319, J1-320, J1-321, J1-322, J1-323, J1-324, J1-325, J1-326, J1-327, J1-328, J1-329, J1-330, J1-331, J1-332, J1-333, J1-334, J1-335, J1-336, J1-337, J1-338, J1-339, J1-340, J1-341, J1-342, J1-343, J1-344, J1-345, J1-346, J1-347, J1-348, J1-349, J1-350, J1-351, J1-352, J1-353, J1-354, J1-355, J1-356, J1-357, J1-358, J1-359, J1-360, J1-361, J1-362, J1-363, J1-364, J1-365, J1-366, J1-367, J1-368, J1-369, J1-370, J1-371, J1-372, J1-373, J1-374, J1-375, J1-376, J1-377, J1-378, J1-379, J1-380, J1-381, J1-382, J1-383, J1-384, J1-385, J1-386, J1-387, J1-388, J1-389, J1-390, J1-391, J1-392, J1-393, J1-394, J1-395, J1-396, J1-397, J1-398, J1-399, J1-400, J1-401, J1-402, J1-403, J1-404, J1-405, J1-406, J1-407, J1-408, J1-409, J1-410, J1-411, J1-412, J1-413, J1-414, J1-415, J1-416, J1-417, J1-418, J1-419, J1-420, J1-421, J1-422, J1-423, J1-424, J1-425, J1-426, J1-427, J1-428, J1-429, J1-430, J1-431, J1-432, J1-433, J1-434, J1-435, J1-436, J1-437, J1-438, J1-439, J1-440, J1-441, J1-442, J1-443, J1-444, J1-445, J1-446, J1-447, J1-448, J1-449, J1-450, J1-451, J1-452, J1-453, J1-454, J1-455, J1-456, J1-457, J1-458, J1-459, J1-460, J1-461, J1-462, J1-463, J1-464, J1-465, J1-466, J1-467, J1-468, J1-469, J1-470, J1-471, J1-472, J1-473, J1-474, J1-475, J1-476, J1-477, J1-478, J1-479, J1-480, J1-481, J1-482, J1-483, J1-484, J1-485, J1-486, J1-487, J1-488, J1-489, J1-490, J1-491, J1-492, J1-493, J1-494, J1-495, J1-496, J1-497, J1-498, J1-499, J1-500, J1-501, J1-502, J1-503, J1-504, J1-505, J1-506, J1-507, J1-508, J1-509, J1-510, J1-511, J1-512, J1-513, J1-514, J1-515, J1-516, J1-517, J1-518, J1-519, J1-520, J1-521, J1-522, J1-523, J1-524, J1-525, J1-526, J1-527, J1-528, J1-529, J1-530, J1-531, J1-532, J1-533, J1-534, J1-535, J1-536, J1-537, J1-538, J1-539, J1-540, J1-541, J1-542, J1-543, J1-544, J1-545, J1-546, J1-547, J1-548, J1-549, J1-550, J1-551, J1-552, J1-553, J1-554, J1-555, J1-556, J1-557, J1-558, J1-559, J1-560, J1-561, J1-562, J1-563, J1-564, J

